




Distributed power amplifier 4 x 1W

Note 1 : insert DC-block or disconnect when using direct power input plug
 Note 2 : power must be fitted with external 2A fuse, no fuse protection inside enclosure
 Note 3 : DC-DC converter reverse-polarity protected by shorting diode